



PB-200 Banjo Pickup System Installation;

Tools you will need;

A Phillips screwdriver

Simple Metal Jack Assembly

- 1) Remove the output jack from the bracket.**
- 2) Position the bracket where it is to be mounted.**
- 3) Slide the long metal clamp bar behind the tensioning hooks and secure the bracket in place with the two supplied screws.**
- 4) Reinstall the output jack.**

Transducer installation;

Each piezo should be mounted on the underside of the head, below the bridge feet on either side. Simply peel off the adhesive backing and press them firmly in place. Use the provided zip-tie to secure the cable to the coordinating rod.

We cannot be responsible for damage caused by installation.

